
# CAMERA MANAGEMENT SOFTWARE



IDIS Center provides customers with plug-and-play management software to install and operate network cameras and network video recorders.


IDIS Center is a central management software solution that supports live monitoring, video playback as well as advanced management tools including event monitoring, emaps and condition monitoring of devices.





# **KEY FEATURES**

- · Remote surveillance of live videos and remote playback of video recordings
- $\cdot$  Real-time notification of detected events and remote monitoring of event videos
- $\cdot$  Panic recording of live videos and playback of panic recordings
- · Registration of up to 1,024 devices
- $\cdot$  Simultaneous remote software upgrades and multiple system setup
- · Displays device's system logs
- · Monitoring live e-map
- · SSL support for security
- · Authority settings by user groups for security
- · Intuitive and user-oriented GUI
- · Supports Removable HDD(SD card) Play
- · All live viewing, searches, e-maps and condition monitoring can be executed simultaneously
- $\cdot$  by displaying distinctly different panels on four different monitors.



# **LIVE VIDEOS**

Live videos of registered sites can be monitored. IDIS Center program receives videos according to the device's settings and displays live videos. Up to 4 Live panels are supported for monitoring live videos.

### 1 Menu

Select the menu System, View, Playback and About.

2 Site List

Used to connect to a registered site using drag & drop

3 Live Event List

Shows instant events and callback events of registered devices. Click button and then Emergency Event Panel will be displayed.

# 4 Live Popup List

Shows the list of current popup screens on IDIS Center.


### 5 Panel Toolbar/Timetable

Shows toolbar or timetable depending on the panel.

### 6 Panel

Shows videos or list of the selected tab.





# **MAP MONITORING**

The camera videos of registered devices, events, and status of connection I/O devices can be monitored on a map. Map monitoring supports up to 4 Live panels and Map panels.



# **SNAP SHOT ON MOTION EVENT**

When 'Motion Event Freeze-frame' is clicked in the Panel Toolbar, still images of videos recorded during Event Record Dwell (Event and pre-event) are shown in the Play panel. Recording information of the selected freeze-frame is displayed on the timetable. When user clicks anywhere on the recorded data on the time table, a freeze-frame image of the selected time is shown. Placing the mouse cursor over the freeze-frame brings up a popup viewer screen above the freeze-frame.



<b>87</b> /-	System	View	Playb	ack About									1
		Play 1		ny 2 Healt		Report Sta	itus						-
otal	Problem			achable	Health	у					ρ,		
21	3		1		17						🕨 🤝 All De		
tatus	Problem	Group	Site 🔺	Address	Version	Cameras	Alarm In	Record	Record Check	Record Period	T Device		
ealthy	Problem	Office1	1st floor	10.0.112.161	1.1.0	1~8	Not Use	On	Good	11-08 20:58:57~1	V 💭 Off	icel 1st floor	
ealthy		OTHER A	3rd floor	10.0.113.201	1.8.0	1~4	Not Use	00	Off	12-09 12:17:41~1	> 20 > 20		
ealthy		Office1	Aisle1	10.0.123.6	NC-D1		Not Use		off		- m		
ealthy		OTTICET	Aisle2	10.0.113.195	1.6.4	1~16	Not Use	00	Off	12-10 03:16:13~1		front door	
ealthy		Office2	Aisle3	10.0.17.223	CDI21	1.10	1101 020			12 10 00110110 - 111		Inside2	
ealthy		Office2	Aisle5	10.0.131.36	NC-EP3							Inside3	
ealthy			Aisle7	10.0.113.187	1.3.1	1+4	Not Use	0n	off	12-08 20:35:48~1			
roblem	Alarm In Bad	Office2	back door	10.0.113.186	2.0.3	1~4	Bad 1	On	Good	12-11 08:16:53~1			
lealthy		Office2	door5	10.0.17.108	DC-D1								
lealthy		Office1	door7	10.0.113.194	1.6.4	1~16	Not Use	On	Off	12-10 20:41:29~1			
roblem	Video Loss	Office1	front door	10.0.113.97	1.1.3	Video Loss 25~32	36	On	Good	12-11 17:11:21-1	► 689		
lealthy		Office2	Inside11	10.0.17.192	DC-F11						🔻 🧊 Off		
lealthy		Office1	Inside2	10.0.123.3	NC-812		Not Use		Off				
lealthy		Office1	Inside3	10.0.123.5	NC-812		Not Use		Off				
lealthy			Inside5	10.0.128.58	NC-542		Not Use		Off		: ► <b>=</b> =		
lealthy		Office1	Inside6	10.0.131.151	NC-EB3								
lealthy		Office1	Inside7	10.0.17.218	DC-F11								
lealthy		Office1	Inside8	10.0.17.167	DC-F11								
lealthy		Office1	Inside9	10.0.131.35	NC-D3		Not Use		Off		A CAMI		
Inreac	Connection ti		Site2	10.0.113.66							🖻 58x2		
roblem		Office1	Site5	10.0.127.130	1.0.3	Video Loss 8	Not Use	off	off	10-11 09:49:48~1	CAM3		
											2 CAM3	3rd floor 3rd floor	12-13 12:2
											ST CAME	3rd floor	12-13 12:2
											at coal 2M		12-13 12:2
											🔊 opal 2M		
											🝂 CAM3		
											🝂 opal 2M		
											🛠 opal 2M		
										1			
											Live Popup		
_													

# SYSTEM STATUS MONITORING

The system status of registered devices can be monitored in realtime. System status monitoring is supported in the Status panel. If a Status tab doesn't exist in the panel tabs, you can add them by selecting New Tab in the System menu and clicking Health. Once Health tab is added, the health monitoring results are automatically displayed.